

# HyperWare® Retail Software

## Quick Reference Card

T7Plus with SPOS 09A

**Note:** Printing a second receipt, the customer receipt, is an option for all transactions.

### Credit Sale

Terminal Display	Action
SWIPE CUSTOMER CARD	Swipe credit card through card reader.
AMOUNT \$0.00	Enter amount of sale, press <b>ENTER</b> .
COMMS	Terminal dials host.
RESPONSE	Approval number is displayed on screen, and printed on receipt.
Approval 123456	

### Debit Sale

Terminal Display	Action
SWIPE CUSTOMER CARD	Press <b>Debit</b> button.
SWIPE CUSTOMER CARD	Swipe card through card reader.
AMOUNT \$0.00	Enter amount of sale, press <b>ENTER</b> .
Waiting for PIN	Customer enters PIN on attached PIN Pad.
COMMS	Terminal dials host.
RESPONSE	Approval number is displayed on screen, and printed on receipt.
Approval 123456	

### EBT Sale

Terminal Display	Action
SWIPE CUSTOMER CARD	Press <b>E-Mail</b> button.
SWIPE CUSTOMER CARD	Swipe card through card reader.
1-FOOD STAMP 2-CASH BENEFIT	Press <b>1</b> for FOOD STAMP or <b>2</b> for CASH BENEFIT, press <b>ENTER</b> .
SALE AMOUNT \$0.00	Enter amount of sale, press <b>ENTER</b> .
Waiting for PIN	Customer enters PIN on attached PIN Pad.
COMMS	Terminal dials host.
RESPONSE	Approval number is displayed on screen, and printed on receipt.
Approval 123456	

### Credit Refund

Terminal Display	Action
SWIPE CUSTOMER CARD	Press <b>Refund</b> button.
SWIPE CUSTOMER CARD	Swipe card through card reader.
AMOUNT \$0.00	Enter amount of refund, press <b>ENTER</b> .
COMMS	Terminal dials host.
RESPONSE	Approval number is displayed on screen, and printed on receipt.
Approval 123456	

### Debit Refund

Terminal Display	Action
SWIPE CUSTOMER CARD	Press <b>Debit</b> and <b>Refund</b> buttons.
SWIPE CUSTOMER CARD	Swipe card through card reader.
AMOUNT \$0.00	Enter amount of refund, press <b>ENTER</b> .
Waiting for PIN	Customer enters PIN on attached PIN Pad.
COMMS	Terminal dials host.
RESPONSE	Approval number is displayed on screen, and printed on receipt.
Approval 123456	



The Global Leader in Electronic Transaction Solutions™

## HyperWare® Retail Software

### Reprint Last Receipt

Terminal Display	Action
SWIPE CUSTOMER CARD	Press <b>Function, 72</b> , then <b>ENTER</b> .
1-MERCHANT RECPT 2-CUSTOMER RECPT	Press <b>1</b> for MERCHANT RECEIPT or press <b>2</b> for CUSTOMER RECEIPT, then <b>ENTER</b> .
REPRINT COMPLETE	Receipt is printed.

### Offline/Force

Terminal Display	Action
SWIPE CUSTOMER CARD	Press <b>Off Line</b> button.
**OFFLINE MODE** ENTER ACCOUNT NUMBER	Enter card number, press <b>ENTER</b> .
EXPIRATION DATE MMY	Enter expiration date, press <b>ENTER</b> .
AMOUNT \$0.00	Enter amount of sale, press <b>ENTER</b> .
ENTER APPROVAL CODE	Enter approval code from voice authorization.
TRANSACTION ACCEPTED	Offline/Force is complete.

### Batch Report (Summary)

Terminal Display	Action
SWIPE CUSTOMER CARD	Press <b>Reports</b> button.
3-AUDIT 4-SUMMARY	Press <b>4</b> , then <b>ENTER</b> .
SCANNING BATCH	Terminal scans for Batch Totals and prints Summary Report.

### Batch Report (Audit)

Terminal Display	Action
SWIPE CUSTOMER CARD	Press <b>Reports</b> button.
3-AUDIT 4-SUMMARY	Press <b>3</b> , then <b>ENTER</b> .
HOST NUMBER	Enter Host Number or '0' for all hosts.
PRINTING	Audit report is printed.

### Batch Settle

Terminal Display	Action
SWIPE CUSTOMER CARD	Press <b>Settle</b> button.
ENTER PASSWORD	Enter password, press <b>ENTER</b> .
HOST NUMBER	Press <b>0</b> for all hosts or enter Host Number, then <b>ENTER</b> .
SCANNING BATCH	Terminal scans for Batch Totals.
SALES TOTAL CORRECT?	Press <b>YES</b> to confirm sale.
REFUND TOTAL CORRECT?	Press <b>YES</b> to confirm refund total.
SCANNING BATCH	Terminal scans for Batch Totals.
COMMS	Terminal dials host.
RESPONSE	Settlement is complete.
Approval 123456	
SCANNING BATCH	Settlement report is printed.



940365-008, rev. D

### World Headquarters

2851 West Kathleen Road • Phoenix, AZ 85053

602.504.5000 • 877.HYPERCOM within USA • Fax: 602.866.5380

e-mail: info@hypercom.com • web: www.hypercom.com

© Hypercom Corporation, 2004. Printed in the United States of America

11/2004

# HyperWare® Retail Software

## Quick Reference Card

T7Plus with SPOS 09A

**Note:** Printing a second receipt, the customer receipt, is an option for all transactions.

### Credit Sale

Terminal Display	Action
SWIPE CUSTOMER CARD	Swipe credit card through card reader.
AMOUNT \$0.00	Enter amount of sale, press <b>ENTER</b> .
COMMS	Terminal dials host.
RESPONSE	Approval number is displayed on screen, and printed on receipt.
Approval 123456	

### Debit Sale

Terminal Display	Action
SWIPE CUSTOMER CARD	Press <b>Debit</b> button.
SWIPE CUSTOMER CARD	Swipe card through card reader.
AMOUNT \$0.00	Enter amount of sale, press <b>ENTER</b> .
Waiting for PIN	Customer enters PIN on attached PIN Pad.
COMMS	Terminal dials host.
RESPONSE	Approval number is displayed on screen, and printed on receipt.
Approval 123456	

### EBT Sale

Terminal Display	Action
SWIPE CUSTOMER CARD	Press <b>E-Mail</b> button.
SWIPE CUSTOMER CARD	Swipe card through card reader.
1-FOOD STAMP 2-CASH BENEFIT	Press <b>1</b> for FOOD STAMP or <b>2</b> for CASH BENEFIT, press <b>ENTER</b> .
SALE AMOUNT \$0.00	Enter amount of sale, press <b>ENTER</b> .
Waiting for PIN	Customer enters PIN on attached PIN Pad.
COMMS	Terminal dials host.
RESPONSE	Approval number is displayed on screen, and printed on receipt.
Approval 123456	

### Credit Refund

Terminal Display	Action
SWIPE CUSTOMER CARD	Press <b>Refund</b> button.
SWIPE CUSTOMER CARD	Swipe card through card reader.
AMOUNT \$0.00	Enter amount of refund, press <b>ENTER</b> .
COMMS	Terminal dials host.
RESPONSE	Approval number is displayed on screen, and printed on receipt.
Approval 123456	

### Debit Refund

Terminal Display	Action
SWIPE CUSTOMER CARD	Press <b>Debit</b> and <b>Refund</b> buttons.
SWIPE CUSTOMER CARD	Swipe card through card reader.
AMOUNT \$0.00	Enter amount of refund, press <b>ENTER</b> .
Waiting for PIN	Customer enters PIN on attached PIN Pad.
COMMS	Terminal dials host.
RESPONSE	Approval number is displayed on screen, and printed on receipt.
Approval 123456	



The Global Leader in Electronic Transaction Solutions™

Need help with your terminal? Call Chris at 1.800.518.6825 for assistance.

## HyperWare® Retail Software

### Reprint Last Receipt

Terminal Display	Action
SWIPE CUSTOMER CARD	Press <b>Function, 7, 2</b> , then <b>ENTER</b> .
1-MERCHANT RECPT 2-CUSTOMER RECPT	Press <b>1</b> for MERCHANT RECEIPT or press <b>2</b> for CUSTOMER RECEIPT, then <b>ENTER</b> .
REPRINT COMPLETE	Receipt is printed.

### Offline/Force

Terminal Display	Action
SWIPE CUSTOMER CARD	Press <b>Off Line</b> button.
**OFFLINE MODE** ENTER ACCOUNT NUMBER	Enter card number, press <b>ENTER</b> .
EXPIRATION DATE MMY	Enter expiration date, press <b>ENTER</b> .
AMOUNT \$0.00	Enter amount of sale, press <b>ENTER</b> .
ENTER APPROVAL CODE	Enter approval code from voice authorization.
TRANSACTION ACCEPTED	Offline/Force is complete.

### Batch Report (Summary)

Terminal Display	Action
SWIPE CUSTOMER CARD	Press <b>Reports</b> button.
3-AUDIT 4-SUMMARY	Press <b>4</b> , then <b>ENTER</b> .
SCANNING BATCH	Terminal scans for Batch Totals and prints Summary Report.

### Batch Report (Audit)

Terminal Display	Action
SWIPE CUSTOMER CARD	Press <b>Reports</b> button.
3-AUDIT 4-SUMMARY	Press <b>3</b> , then <b>ENTER</b> .
HOST NUMBER	Enter Host Number or '0' for all hosts.
PRINTING	Audit report is printed.

### Batch Settle

Terminal Display	Action
SWIPE CUSTOMER CARD	Press <b>Settle</b> button.
ENTER PASSWORD	Enter password, press <b>ENTER</b> .
HOST NUMBER	Press <b>0</b> for all hosts or enter Host Number, then <b>ENTER</b> .
SCANNING BATCH	Terminal scans for Batch Totals.
SALES TOTAL CORRECT?	Press <b>YES</b> to confirm sale.
REFUND TOTAL CORRECT?	Press <b>YES</b> to confirm refund total.
SCANNING BATCH	Terminal scans for Batch Totals.
COMMS	Terminal dials host.
RESPONSE	Settlement is complete.
Approval 123456	
SCANNING BATCH	Settlement report is printed.



The Global Leader in Electronic Transaction Solutions™

### World Headquarters

2851 West Kathleen Road • Phoenix, AZ 85053

602.504.5000 • 877.HYPERCOM within USA • Fax: 602.866.5380

e-mail: info@hypercom.com • web: www.hypercom.com

© Hypercom Corporation, 2004. Printed in the United States of America

940365-008, rev. D

11/2004